



25 13/16"

THIS IS WHERE THE RV ATTACHES. I REMOVE THE FRONT BAR BUT THE (2) RECEIVERS DOWN BELOW THE BUMPER ARE STILL THERE, SITTING LOW TO THE GROUND. IF THE 2 SETS OF TOW TABS WERE ON THE BUMPER, IT WOULD GIVE US A LOT MORE GROUND CLEARANCE.

31 7/16"



TOW BAR DETAILS. WOULD LIKE THESE TO ATTACH TO THE NEW FRONT BUMPER.

These pins go through those little tabs you see in the other picture. They keep the pins from rotating.

Outer edge

Inner  
edges

